

Safety Mode

Safety Mode can be used for professional and high secure management. Normal Mode is enough for general use, because managing Safety Mode is more complicated than Normal Mode.

I Registration Button
(Open Battery Cover)

R Registration Button
(Open Battery Cover)

R Remote
Registration Button
on Remote control

NEW
MP New Master PIN Code

MP Master PIN Code

UP User PIN Code

ONE
UP One Time
User PIN Code

CARD
Enter
Card Key

! Important

- Master PIN Code $\neq$ User PIN Code $\neq$ One Time PIN Code.
- When Safety Mode, Fake PIN Code cannot be used.
- It is impossible to change mode by using Card Key, User PIN Code and One Time PIN Code.
- When mode change from Safety Mode to Normal Mode.
 - Most registration information(Card Key, User PIN Code, One Time PIN Code) is removed.
 - Remote controller information is not removed.
- When mode change from Normal Mode to Safety Mode.
 - Most registration information(Card Key, User PIN Code) is removed.
 - Remote control information is not removed.
- One Time PIN Code doesn't support setting of Outside Forced Lock and Releasing Alarm.

Setting

Change Mode (Normal Mode $\rightarrow$ Safety Mode)

R or **I** **#** **41** **NEW** **MP** **R** or **I**

• When already Safety Mode,
this process doesn't work
User Pin Code is removed after
changing mode

Change Master PIN Code (Old $\rightarrow$ New)

OLD **MP** **R** or **I** **#** **09** **NEW** **MP** **R** or **I**

One Time User PIN Code

MP **R** or **I** **#** **07** **ONE** **UP** **R** or **I**

• When Normal Mode,
this process doesn't work

Change Mode (Safety Mode $\rightarrow$ Normal Mode)

MP **R** **I** **#** **43** **MP** **R** or **I**

• When already Normal Mode,
this process doesn't work
• Current Master PIN Code is
changed to User PIN Code

To register User PIN Code / Card Key / Remote control

Register PIN Code / Card Key

MP **R** or **I** **UP** or **CARD** **R** or **I**

Register Remote control

MP **R** or **I** **#** **05** **Remote** **R** **R** or **I**

Delete Remote control

MP **R** or **I** **#** **75** **R** or **I**

安全模式

安全模式提供您更高保安的使用模式。

貼心提醒您：一般模式的安全程度已非常足夠，較複雜的安全模式建議使用在需管理門禁的狀況下。

I 設定鍵

R 設定鍵

Remote R 遙控器設定鍵

NEW MP 新管理者密碼

MP 管理者密碼

UP 使用者密碼

ONE UP 一次性密碼

CARD 登記卡片

! 貼心提醒

- 管理者密碼 不等於 使用者密碼 不等於 一次性密碼。
- 在安全模式下，無法使用虛位密碼。
- 當您從安全模式變更到一般模式時：
 - 會刪除所有已登記的卡片, 密碼, 一次性密碼。
 - 登記過的遙控器不會被刪除。
- 當您從一般模式變更到安全模式時：
 - 會刪除所有已登記的卡片, 密碼。
 - 登記過的遙控器不會被刪除。
- 一次性密碼僅供一次性開門使用, 無法用來解除警報或設定外部強制上鎖。

設定

變更模式 (一般模式 → 進階模式)

R or I # 4 1 NEW MP R or I

- 當您已經為安全模式時，此變更不會有反應。
- 變更模式後使用者密碼會清除。

變更管理者密碼 (舊 → 新)

MP R or I # 0 9 MP R or I

一次性密碼

MP R or I # 0 7 ONE UP R or I

- 一般模式下，無法使用此功能

變更模式 (安全模式 → 一般模式)

MP R I # 4 3 MP R or I

- 當您已經為一般模式時，此變更不會有反應。
- 變更模式後管理者密碼會自動變成使用者密碼。

登記使用者密碼/卡片/遙控器

登記密碼/卡片

MP R or I UP or CARD R or I

登記遙控器

MP R or I # 0 5 Remote R R or I

刪除遙控器

MP R or I # 7 5 R or I