



## **SIREN BASED SYSTEM**

(Quick Setup Instructions)

- 1) On the siren: power switch to OFF, then switch 4 to Master (ON), switch 2 to OFF, switch 3 to OFF, switch 1 to ON. Press the discharge switch (Learn button on the siren) a couple of times.



Clear



Normal Master

- 2) Move the power switch to ON (the siren will beep and flash), move the clear switch (switch 1) to OFF.
- 3) Pull out the plastic tabs in all the detectors and the keypad.
- 4) Press and hold the learn button on the siren (the siren will beep and LED 1 & 3 flash).
- 5) Press Panic A then 0000, Panic A and 1 on the keypad (the siren will beep and flash) then Press DISARM twice.
- 6) Press the learn button on the siren once (LED 2 flash). Press the blue DISARM button on the keypad and type in 0000 (or the PIN number).
- 7) Press panic 'A', enter 0000 press panic 'A' again then 2 (siren beeps) then Press Panic A and 4 (siren beeps).
- 8) Press and hold the test button for about 3 seconds on all the detectors one at a time (the siren will beep and flash each time), it is now advisable to move the PIRs to a different room.
- 9) Press Panic A and 5 then DISARM twice to exit programming
- 10) The system is set and can be mounted. (the tampers are disabled for 1 hour) Changing PIN number:

### **Changing the PIN number:**

- Press panic A enter 0000, press panic B enter new (4 digit) pin code, press ARM (Red Button with closed padlock) to confirm, press DISARM (Green open Padlock button) twice to exit programming.

### **Using the system:**

- ARM: Press and hold the ARM button (for 1 second)
- DISARM: Press the DISARM button and enter the pin number