FITTING INSTRUCTIONS V-8K116

Fitting instructions

Prior to fitting familiarise yourself with it s simple action. If fitting doors it may be necessary to drill small pilot holes for the wood fixing a

WOOD HINGED DOORS

1. Position lock body horizontally or vertically a minimum of 19mm(3/4) for door edge. Mark and prepare fixing holes. Re-position lock and insert goodoured woodscrews, remove screws and replace with one way screws for exsecurity. Determine position of locking plate, mark around it sedge and so it lies flush with frame. Mark and prepare fixing holes and secure lowith shorter woodscrews. Do not overtighten.

METAL AND WOOD HINGED DOORS (Locking plate not required)

 ${\bf 2.} \; {\rm Position} \; {\rm lock} \; {\rm body} \; {\rm vertically} \; {\rm on} \; \; {\rm sliding} \; {\rm door} \; \; {\rm frame} \; {\rm a} \; {\rm minimum} \; {\rm of} \; 19 \, {\rm mm} \, (3, 1) \, {\rm the} \; \; {\rm track} \, .$


WOOD: Mark and prepare fixing holes and fit lock body to frame with gold woodscrews. Operate bolt to mark position of bolt hole. Remove lock and 9mm(3/8) dia hole to suite bolt length, fit ferrule into bolt hole. Revery supplied for extra security. Do not overtighten. Check opera


METAL: Mark fixing holes and carefully drill with a 4mm(5/32) drill bit. coloured thread cutting screws. Operate bolt to mark position of bolt lock, discard screws, and drill a 9mm(3/8) dia hole to suit bolt length, bolt hole. Re-fit lock using one way bolt supplied. Do not overtighten. operation.

Note: Ventilation position for sliding doors can be added by drilling extra Do not allow door to open more than 100mm (4), fit ferrule into addition hole.

 ${\bf NB.}$ Equivalent imperial sizes are approximate.

Not recommended for exterior use. Do not use abrasive cleaners, solvents only use moist soft cloth.







The world's favourite lock

www.yale.co.uk E-mail: locksinfo@yale.co.uk

Yale 2 Year Guarantee Statement

This product is guaranteed for consumers against faulty workmanship, materials and function for a period of 2 years from the date of purchase providing the full installation and maintenance instructions are followed. Please keep your proof of purchase safe, this must be submitted when making a claim under this guarantee.

Please note that it is a condition of this guarantee that your Yale product:

- Has been correctly installed and maintained in accordance with the Yale installation and maintenance instructions provided to you at the time of purchase.
- · Has not been modified or damaged in any way.
- Has not been subjected to unauthorized repairs.

Yale are responsible under this guarantee for repairing the product or replacing the product as we deem necessary. If there is fault with the product, please contact Customer Services on 01902 364647, who will give you the name of an expert and confirm what you need to do to make a claim under this guarantee.

Please do not carry out any repairs without our authority or by using an unauthorised expert. Any repairs or other works carried out without our authorization or by using an unauthorized expert will not be covered under this guarantee.

This guarantee is non transferrable and applies to products purchased in the United Kingdom only. This guarantee does not apply to normal wear and tear. This does not affect your statutory rights. A full copy of this guarantee is available upon request by writing to Yale UK, School Street, Willenhall, West Midlands. WV13 3PW or by visiting our website www.yale.co.uk.