smart Yale® Living

Home View Pan, Tilt, Zoom Camera (WIPC-303W)

Quick Start Guide

LENS

Microphone

SD Card Slot

Audio Input
Audio Output

Reset/WPS Button   Mounting Port

Speaker

Antenna

I/O Alarm
Power

Network light   LAN
Power light

Inside the Box

Home View Pan Tilt Zoom Camera

AC Power Adapter

Mounting Bracket

Ethernet Cable

Quick Installation Guide

Wi-Fi Antenna

For more information on this product and Yale Smart Living Range visit
**www.yale.co.uk/smart-living**
Consumer Support: info@yale.co.uk

ASSA ABLOY

An ASSA ABLOY Group brand

Mounting Your Home View Camera

The Home View Camera can be free standing or fixed in place. To mount your Home View Camera, please follow the steps below.

1. Screw the mount on the wall with the two screws provided.

2. Loosen the thumb screws to adjust the mount to the desired position. Once the position is set, tighten the screws securely.


Network Light Status

Network Light	Description
Constant Light	Wired connection
Flashing every 0.2 seconds	Wireless Connection (default)
Flashing every 0.4 seconds	WPS is connecting
Slow Flash every 1.0 second	Wi-Fi connected

Hardware Connection

1. Fit Wi-Fi antenna to your Home View Pan, Tilt, Zoom Camera and position upright.

2. Connect the AC power adapter to the camera.

3. Ensure your wireless router is turned on and connected to the internet.

Before you continue, please note:

• Make sure your Smartphone is located near the camera.

• Do not use an ethernet cable to connect the camera if you want to use a wireless connection.

• Make sure your Smartphone is connected to your wireless router.

To View & Operate Via Smartphone

1. Go to the App Store or Google Play Store and search for the Yale Home View App.

2. Download and Install the App.

3. To add the IP Camera, open the App and tap the '+' button on the App and follow the setup wizard to add your camera.

Issue No. 1A

PACKAGING

ASSA ABLOY

An ASSA ABLOY Group brand