



**STANDARD
SECURITY**

Yale®

2 Lever Lock

Recommended for use on
internal timber doors


- For use with door handles
- Suitable for both left and right handed doors



**CHROME
FINISH**

FOR MORE INFORMATION SEE BACK OF PACK





Mortice locks are sized by the depth of the lock case and the rectangular hole – the “mortice” – into which the lock fits.

If you are replacing an existing mortice lock, you can find out what size you need without removing your old lock.

Simply measure from the edge of the door to the centre of the keyhole. If the measurement is 45mm (1³/₄”), you need a 64, 65 or 67mm (2¹/₂”) mortice lock. If the measurement is 57mm (2¹/₄”), you need a 76, 78 or 80 mm (3”) mortice lock.

FOR FULL FITTING INSTRUCTIONS SEE INSIDE PACK

Tools required:

- Drill brace

Required Drill Bits:

- Ø10mm (3/8")
- Ø19mm (3/4")
- Ø22mm (7/8")
- 19mm (3/4") chisel
- Bradawl
- Mallet
- Pozidrive screwdriver
- Pencil
- Scissors

Other Yale products:



Door handles & knobs

Alarm Kits


Stand alone alarms

Safes

CCTV



Recommended Back Door Security



1 Mortice Lock

Standard Security
PM320 3 Lever Lock

Standard Security
PM236 2 Lever Lock

2 Door Bolts

PM444

3 Hinge Bolts

P125 (for outward opening doors only)



MANUFACTURERS WARRANTY
GUARANTEED AGAINST FAULTY
MATERIALS AND WORKMANSHIP



The world's favorite lock

Yale

School Street, Willenhall,
West Midlands WV13 3PW
Tel: +44 (0) 1902 364606
Fax: +44 (0) 1902 364692
Email: info@yale.co.uk
www.yale.co.uk



PACKAGING

PM-246-CH-64



5 010608 024655 >