



P402 Rim Lock Fitting Instructions

Tools Required



Drill



**Required
Drill Bits:**
Ø8mm
Ø3mm



19mm
chisel



Bradawl



Mallet



Crosshead
Screwdriver



Pencil

Fitting Instructions

1. If replacing rim lock, remove existing lock from door and place the case of the lock over existing keyhole.
2. Fix the new lock using the screws provided.
3. If fitting on a new door, mark a point on the door at the height you require. Measuring in from the edge of the door, drill an 8mm hole 47mm in from the doors edge. 11mm directly below the hole you have just created, drill another 8mm hole ensuring it is exactly level with the hole above.
4. Using a chisel, remove the wood in between the two holes to create an oval keyhole.
5. Line up the keyhole you have created in the door to the keyhole on the lock case and mark the 3 screw holes, drilling pilot holes if required.
6. Fix the lock case to the door.
7. Mark the required position for the lock keep on the door frame – ensuring it lines up with the lock case when the door is closed.
8. If necessary, remove a section of the door frame to enable the keep to be fitted.
9. Mark positions for the 2 fixing screws and drill pilot holes if required.
10. Use the 2 screws provided to fit the lock keep.



The world's favourite lock since 1843

School Street, Willenhall, West Midlands WV13 3PW
www.yale.co.uk Tel: +44 (0) 1902 364647 E-mail: info@yale.co.uk

Issue No: 01-2012